Replacement Parts for Wall Mount Faucets 16" SWING SPOUT 3964 14" SWING SPOUT 8" ADJ. WALL CONTROL VALVE 3963 12" SWING SPOUT 3962 10" SWING SPOUT 2000-7500 SCREW 3961 2000-8000 8" SWING SPOUT **RED BUTTON** AND 2000-8001 BLUE BUTTON 3960 6" SWING SPOUT 3984-2300 15621 WRIST HANDLE SPOUT NUT 89621 12564 RH SWIVEL STEM 2002 2.2 GPM SNAP RING REPAIR KIT 2000-3002 **AERATOR BIBB CAP** 1600-5000 89613 8 LH SWIVEL STEM SPOUT O-RING REPAIR KIT 10464 **DUCK GASKET** 10456 10014 (24") LUBE 10022 (36"") 2000-5000 SUPPLY LINE WASHER 19119 1/2" F X 1/2"F SWIVEL SPOUT RETRO-FIT KIT 3000-0010 10049 (24") LH SWIVEL STEM 10006 (36"") SUPPLY LINE 3000-0011 1/2" M X 1/2"F RH SWIVEL STEM 16101 FLAT SEAT 2400-2103 WASHER 1000-7502 **ELBOWS** SCREW 1792 ANGLE STOP WITH KEY 10456 3000-0003 1790-1 DOUBLE JOINT LUBE ANGLE STOP SPOUT 7 1/2" WITH CROSS **HANDLES** 4000-0002 DOUBLE JOINT SPOUT 14" 3200-2306 3200-2307 2200-5000 **ECCENTRIC** 1/2" ECCENTRICS **ECCENTRIC GASKETS FLANGES** 2200-0000

MANUFACTURING COMPANY PO BOX 60, TULARE, CA 93275 (800)421-6162, FAX: (800)832-8238

www.fisher-mfg.com

Part No. - 73308



8" Adjustable Wall Mount Faucet **Product Installation Guide**

Fisher Manufacturing Com-Since has manufactured heavy-duty. quality plumbing products and hardware specialties for the food service industry. For three generations, the Fisher family has adhered to a strict dedication of and overall value. When you install Fisher products... you install the best. Our hardware is manufactured with the standardization of internal mechanisms. All chrome plating is triple plated copper, nickel and chrome for durability. Every piece of equipment we make is rigorously tested in both our modern in-house testing center and in actual field situations under extreme conditions. Every detail is thoroughly checked. Before we make our products available to you, they pass each and every test. You get proven performance. Guaranteed.



Fisher Manufacturing Company warrants its products and parts thereof (except as noted below) against defects in materials or workmanship for a period of one year after the date of original purchase. During this period Fisher Manufacturing Company will replace a defective product or part without charge to you, provided that the entire product is delivered to Fisher Manufacturing Company. All transportation and insurance charges for shipping the product to and from Fisher Manufacturing Company must be borne by you. Charges for transportation and insurance may, at the option of Fisher Manufacturing Company, be refunded depending upon our investigation of the warranty claim. This warranty does not cover external finish (except at date of original purchase) or labor costs not specifically authorized by Fisher Manufacturing Company.

A full and complete copy of our One Year limited warranty is available upon request.

WARNING:

SLIP JOINT KIT

REV.A

Proposition 65 requires that we provide you with the following notice: "This product Contains A Chemical Known To The State Of California To Cause Birth Defects Or Other Reproductive Harm."

d'5nafem

#91383 - 8" Adi. Wall Mount Faucet with 6" Swing

#91553- 8" Adj. Wall Mount Faucet with 8" Swing

#91235 - 8" Adj. Wall Mount Faucet with 10" Swing Spout

#91065 - 8" Adj. Wall Mount Faucet with 12" Swing Spout

#94706 - 8" Adj. Wall Mount Faucet with 14" Swing Spout

#93467 - 8" Adj. Wall Mount Faucet with 16" Swing Spout





ANSI/A112.18.1M, ANSI/NSF 61.9



Installation Instructions for Wall Mount Faucet


BE SURE TO CHECK WITH YOUR LOCAL DEPARTMENT HAVING JURISDICTION REGARDING BACKFLOW PREVENTION.

Installation Notes:

- Be sure water supply is shut-off before beginning.
- Use pipe thread sealant on all threaded joints such as PST or Teflon tape.
- Check the packaging for missing items BEFORE beginning installation. If items are missing, contact your supplier.

Package Contents

The box should contain the following:



Each spout includes one 2002 snap ring and two 1600-5000 O-rings



Eccentric Flanges

Qty: 2

3200-2307 1/2" Eccentrics

Qty: 2





Items needed for Installation

- 1 Medium Sized Crescent Wrenches
- 1 Plumbers Tape or Pipe Thread Sealant





Installation Instructions

Step 1.

After unpacking items and checking for missing components, insert and center the gasket into the female swivel inlets of the 8" control valve body. Loosely mount the eccentrics and flange onto the control valve body.

Step 2.

Mount control valve body to either a wall with a male supply nipples, or backsplash with nipples (not included). Be sure to use pipe thread sealant on the supply nipple threads. Adjust the eccentrics as needed in order to mount the control valve level. Once level, tighten the eccentrics

Step 3.


Optional DJ swivel spout, apply lube to the O-ring on the spout. Mount the DJ swivel spout and tighten the nut onto the faucet spout outlet.

Step 4

Apply O-ring lube to the O-rings on the swing spout. Make sure the white snap ring is in place before mounting the swing spout. Mount the swing spout and tighten the swing spout nut onto the faucet spout outlet.

Step 5.

Turn on water supply and check for leaks.



Installation Instructions Continued

